



# CABLING DIAGRAM – RENOVATION INTERCOM WITH CENTRAL UNIT 03-0101



Cabling diagram – Renovation intercom with central unit 03-0101

# CABLING FOR THE PUSH BUTTON AND ENTRANCE DOOR

Two possible cabling methods: to the central unit **OR** to the intercom:



Cabling diagram – Renovation intercom with central unit 03-0101